Алматы (7273)495-231 Ангарск (3955)60-70-56 Архангельск (8182)63-90-72 Астрахань (8512)99-46-04 Барнаул (3852)73-04-60 Белгород (4722)40-23-64 Благовещенск (4162)22-76-07 Брянск (4832)59-03-52 Владикавказ (8672)28-90-48 Владикавказ (8672)28-90-48 Владикарказ (844)278-03-48 Волоград (844)278-03-48 Вологра (8172)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89 Ижевск (3412)26-03-58 Иваново (4932)77-34-06 Иркутск (395)279-98-46 Казань (843)206-01-48 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (3332)68-02-04 Коломна (4966)23-41-49 Кострома (4942)77-07-48 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курск (4712)77-13-04 Курган (3522)50-90-47 Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Новобирск (3496)41-32-12 Новобирск (3496)41-32-12 Омск (3812)21-46-40 Орел (4862)44-53-42 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Петрозаводск (8142)55-98-37 Псков (8112)59-10-37

Россия (495)268-04-70

Ростов-на-Дону (863)308-18-15 Рязань (4912)46-61-64 Самара (846)206-03-16 Саранск (8342)22-96-24 Санкт-Петербург (812)309-46-40 Саратов (845)249-38-78 Севастополь (8692)22-31-93 Симферополь (3652)67-13-56 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Сыктывкар (8212)25-95-17 Сургут (3462)77-98-35 Тамбов (4752)50-40-97

Пермь (342)205-81-47

Тольяти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульян-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Тверь (4822)63-31-35

https://kitchenaid.nt-rt.ru | kdi@nt-rt.ru

Принадлежности для посудомоечных машин

KitchenAid 24" Dishwasher Panel Kit - Stainless Steel

0.0 (0) Model: KDAS104HSS



KitchenAid 24" Dishwasher Panel Kit - Stainless Steel

Match the look of your dishwasher to your kitchen. This KitchenAid® panel kit coordinates with the rest of your appliances for a seamless fit with your kitchen. Dishwasher and panel kit sold individually.

Dishwasher Drain Hose Extension

4.6 (46) | **Model:** 8269144A



Dishwasher Drain Hose Extension

This Dishwasher Drain Hose Extension sends waste water from the drain hose loop to the house drain during your appliance's operation. This accessory is compatible with most dishwasher brands and models and will be needed if your appliance is more than the standard distance away from the house drain; check to see if your model number is compatible. Installing this accessory will require basic hand tools, some disassembly of the appliance and novice repair experience. You must unplug the appliance or shut off the house circuit breaker before installing this accessory. Also make sure you turn off the water supply under the sink. Helpful Tip: We also recommend using affresh® Dishwasher Cleaner (item W10282479) once a month or as needed, to help remove limescale and mineral buildup that can affect your dishwasher's performance. *affresh® brand products are owned and distributed by Whirlpool Corporation.

Dishwasher Water Supply Hose Kit

0.0 (0) | Model: 4396897RW





Dishwasher Water Supply Hose Kit

This Dishwasher Water Supply Hose Kit connects the dishwasher to the house water supply. This is a universal part that can be used across several brands; check to see if your model number is compatible. The kit includes (1) 6' industrial-grade nylon braided hose with standard connection and brass elbow. Installing this accessory will require basic hand tools, some disassembly of the dishwasher and novice repair experience. You must unplug the dishwasher or shut off the house circuit breaker for the appliance before installing this part. Also make sure you turn off the water supply. Helpful Tip: We also recommend using affresh® Dishwasher Cleaner* (item W10282479) to help remove limescale and mineral build-up that can be unsightly and affect your dishwasher's performance. *affresh® brand products are owned and distributed by Whirlpool Corporation.


Dishwasher Silverware Basket

3.7 (3) | **Model:** 3370993RB



Dishwasher Silverware Basket Extension Kit


3.7 (3) | Model: DISHEXTEND



Dishwasher Water Line Installation Kit

0.0 (0) | **Model:** W10278636RC





Dishwasher Drain Hose

5.0 (2) **Model:** 8531858





Oiled Bronze Appliance Touchup Paint

5.0 (1) **Model:** W10134193





Cleaning up after successfully tackling a new technique or recipe is often a home cook's least favorite step. KitchenAid® dishwashers were designed to take the hassle out of mealtime chores, and our dishwasher accessories as well as installation and repair kits will help you keep this essential appliance in top form. Whether you need installation kits for your new appliance, want to enhance or maintain aesthetics with towel bar handles and touch-up paint or have to make minor updates to your water supply hose or dishwasher rack, we have the repair kits and accessories you need to get started. Browse our full offering of dishwasher components that will help you maintain your appliance over time, or contact our customer service center to schedule larger dishwasher repairs.

Dishwasher Water Line Supply Kit

0.0 (0) | **Model:** W10278625RP





Black Lava Appliance Touchup Spray Paint

0.0 (0) | **Model:** W10868016





Cleaning up after successfully tackling a new technique or recipe is often a home cook's least favorite step. KitchenAid® dishwashers were designed to take the hassle out of mealtime chores, and our dishwasher accessories as well as installation and repair kits will help you keep this essential appliance in top form. Whether you need installation kits for your new appliance, want to enhance or maintain aesthetics with towel bar handles and touch-up paint or have to make minor updates to your water supply hose or dishwasher rack, we have the repair kits and accessories you need to get started. Browse our full offering of dishwasher components that will help you maintain your appliance over time, or contact our customer service center to schedule larger dishwasher repairs.

Dishwasher Upper Rack Adjuster Kit

1.3 (10) **Model:** W10712394





Dishwasher Water Supply Hose Kit

5.0 (2) | **Model:** 8212486





Dishwasher Side Cabinet Bracket Kit

5.0 (2) | **Model:** 8212560





Cleaning up after successfully tackling a new technique or recipe is often a home cook's least favorite step. KitchenAid® dishwashers were designed to take the hassle out of mealtime chores, and our dishwasher accessories as well as installation and repair kits will help you keep this essential appliance in top form. Whether you need installation kits for your new appliance, want to enhance or maintain aesthetics with towel bar handles and touch-up paint or have to make minor updates to your water supply hose or dishwasher rack, we have the repair kits and accessories you need to get started. Browse our full offering of dishwasher components that will help you maintain your appliance over time, or contact our customer service center to schedule larger dishwasher repairs.

Dishwasher Power Cord

3.0 (4) **Model:** 4317824





Dishwasher Rack Repair Kit

5.0 (2) **Model:** 4396840RC





Cleaning up after successfully tackling a new technique or recipe is often a home cook's least favorite step. KitchenAid® dishwashers were designed to take the hassle out of mealtime chores, and our dishwasher accessories as well as installation and repair kits will help you keep this essential appliance in top form. Whether you need installation kits for your new appliance, want to enhance or maintain aesthetics with towel bar handles and touch-up paint or have to make minor updates to your water supply hose or dishwasher rack, we have the repair kits and accessories you need to get started. Browse our full offering of dishwasher components that will help you maintain your appliance over time, or contact our customer service center to schedule larger dishwasher repairs.

Tall Tub Dishwasher Drain Hose Extension

5.0 (2) **Model:** 3385556



Dishwasher Water Line Installation Kit

5.0 (2) | **Model:** 8212488RC



Cleaning up after successfully tackling a new technique or recipe is often a home cook's least favorite step. KitchenAid® dishwashers were designed to take the hassle out of mealtime chores, and our dishwasher accessories as well as installation and repair kits will help you keep this essential appliance in top form. Whether you need installation kits for your new appliance, want to enhance or maintain aesthetics with towel bar handles and touch-up paint or have to make minor updates to your water supply hose or dishwasher rack, we have the repair kits and accessories you need to get started. Browse our full offering of dishwasher components that will help you maintain your appliance over time, or contact our customer service center to schedule larger dishwasher repairs.

Dishwasher Elbow Hose Fitting

0.0 (0) **Model:** W10278626RP



Dishwasher Power Supply Kit

0.0 (0) | **Model:** W10278923RP









Dishwasher Water Inlet Fitting

0.0 (0) | **Model:** W10685193





CHECK AVAILABILITY

Dishwasher Handle Kit

0.0 (0) | **Model**: W10708004





Cleaning up after successfully tackling a new technique or recipe is often a home cook's least favorite step. KitchenAid® dishwashers were designed to take the hassle out of mealtime chores, and our dishwasher accessories as well as installation and repair kits will help you keep this essential appliance in top form. Whether you need installation kits for your new appliance, want to enhance or maintain aesthetics with towel bar handles and touch-up paint or have to make minor updates to your water supply hose or dishwasher rack, we have the repair kits and accessories you need to get started. Browse our full offering of dishwasher components that will help you maintain your appliance over time, or contact our customer service center to schedule larger dishwasher repairs.

Dishwasher Handle Assembly, Black

0.0 (0) | **Model**: W10907189





Dishwasher Rack Repair Kit

5.0 (2) **Model:** 4396838RC





Cleaning up after successfully tackling a new technique or recipe is often a home cook's least favorite step. KitchenAid® dishwashers were designed to take the hassle out of mealtime chores, and our dishwasher accessories as well as installation and repair kits will help you keep this essential appliance in top form. Whether you need installation kits for your new appliance, want to enhance or maintain aesthetics with towel bar handles and touch-up paint or have to make minor updates to your water supply hose or dishwasher rack, we have the repair kits and accessories you need to get started. Browse our full offering of dishwasher components that will help you maintain your appliance over time, or contact our customer service center to schedule larger dishwasher repairs.

Dishwasher Drain Hose

0.0 (0) **Model:** W11381654





Алматы (7273)495-231 Ангарск (3955)60-70-56 Архангельск (8182)63-90-72 Астрахань (8512)99-46-04 Барнаул (3852)73-04-60 Белгород (4722)40-23-64 Благовещенск (4162)22-76-07 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Владикавказ (8672)28-90-48 Владимир (4922) 49-43-18 Волгоград (844)278-03-48 Вологорад (8472)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89 Ижевск (3412)26-03-58 Иваново (4932)77-34-06 Иркутск (395)279-98-46 Казань (843)206-01-48 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04 Коломна (4966)23-41-49 Кострома (4942)77-07-48 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курск (4712)77-13-04 Курган (3522)50-90-47 Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Ноябрьск (3843)20-46-81 Ноябрьск (3496)41-32-12 Ноябрьск (3496)41-32-12 Омск (3812)21-46-40 Орел (4862)44-53-42 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Петрозаводск (8142)55-98-37 Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35
Тольяти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Черябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Ккутск (4112)23-90-97
Ярославль (4852)69-52-93